

Пружинные донные клапаны Н42Х, Н12Х

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Россия (495)268-04-70

Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Киргизия (996)312-96-26-47

Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Казахстан (7172)727-132

Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Spring Foot Valve

Usage: At the downstream of the water sucking pipelines, the valve can automatically prevent water from flowing backward.



Product Description




Spring Foot Valve – Product Description (1)



Spring Foot Valve – Product Description (2)



Spring Foot Valve - Product Description (3)



Spring Foot Valve - Product Description (4)

Product Parameters

H42X-10 H12X-10 型升降式底阀

H42X-10 H12X-10 Lifting bottom valve

用途: 本阀门安装在水泵吸水管路的底端, 能自动阻止流体倒流。

Usage: At the downstream of the water sucking pipelines, the valve can automatically prevent water from flowing backward.




主要零件材料 Main parts and materials

零件名称 Parts name	材料 Material
阀体、阀罩、阀瓣 Valve body, Valve cover, Disc	灰铸铁 Grey iron
密封圈 Seal ring	氟橡胶 PTFE


性能规范 Function and specification

型号 Type	公称压力 Nominal pressure (MPa)	试验压力 Testing pressure		适用温度 Suitable temperature (°C)	适用介质 Suitable medium
		强度(水) Strength (Water) (MPa)	密封(水) Seal (Water) (MPa)		
H42X-10	1.0	1.5	1.1	≤50	水 Water
H12X-10					



外型尺寸和连接尺寸 Outline and connecting measurement

型号 Type	公称口径 Nominal DN (mm)	尺寸 Measurement (mm)							
		D	D1	D2	b-f	Z-φd	D0	h0	H
H42X-10	50	160	125	100	20-3	4-φ18	145	20	145
	65	180	145	120	20-3	4-φ18	160	20	161
	80	195	160	135	22-3	4-φ18	190	26	177.5
	100	215	180	155	22-3	8-φ18	230	30	213
	125	245	210	185	24-3	8-φ18	260	35.5	236
	150	280	240	210	24-3	8-φ23	343	43.5	315
	200	335	295	265	26-3	8-φ23	429	60	380
	250	390	350	320	28-3	12-φ23	501	71	468
	300	440	400	368	28-4	12-φ23	566	82	552



外型尺寸和连接尺寸 Outline and connecting measurement

型号 Type	G	D	H	h0
H12X-10	1/2	96	98.5	5
	3/4	128	116	7
	1	120	145	8
	1 1/4	138	152	10
	1 1/2	140	164	21
	2	148	184	23

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Россия (495)268-04-70

Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Киргизия (996)312-96-26-47

Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Казахстан (7172)727-132

Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93